

### Product Code

**UTB-0260E Solubility Test Set for Bitumen and Bituminous Binders**  
**UTGG-2005 Filter Flask, 500 ml**  
**UTGG-2240 Gooch Crucible, Glass, for UTB-0260**  
**UTGG-2242 Funnel for UTB-0260, Glass**  
**UTGG-2244 Powdered Glass, for UTB-0260, 100 g**  
**UTGP-1222 Rubber Stopper with a hole, for UTB-0260**  
**UTGP-1226 Rubber Ring, for UTB-0260**  
**UTGG-3590 Water Trompe/Aspirator Filter Pumps for Vacuum Filtration with Analog Manometer**

### Standards

EN 12592

Solubility Test Set is used for determining the degree of solubility of bituminous binders having little or no mineral matter other than recovered bituminous binders from asphalt mixes.

The test set includes of a filter flask, a sintered glass crucible, a funnel, 100g powdered glass, a rubber ring and a rubber stopper. UTGE-3590 Metal water trompe/aspirator filter pump is supplied complete with 2m plastic tube, 1m rubber tube and 4 pcs. tube clamps.

Solvent and water trompe should be ordered separately.



Dimensions	300x250x300 mm
Weight (approx.)	15 kg