

Product Code

UTS-0680-T Vibratory Hammer for Compaction of Bituminous and Soil Mixtures, 220-240V, 50 Hz, 1ph.
UTS-0681 Supporting Frame for Vibratory Hammer
UTS-0682 Large Tamping Foot, Ø146 mm
UTS-0684 Shank for UTS-0680
UTAS-0885 P.R.D. Split Mould and Base Plate

Standards

EN 12697-32, 12697-9, 12697-10, 13286-4; BS 1377-4

The UTS-0680 Vibratory compaction apparatus are used for preparing the test specimens of bituminous mixtures and soils.

P.R.D. (Percentage Refusal Density) Split Mould is split vertically on one side, attached to the base plate with clamp. Plated against corrosion.

UTAS-0885 The split mould and base plate should be ordered separately.

Supporting frame for vibratory hammer (UTS-0681), shank (UTS-0684), Ø146 mm large tamping foot (UTS-0682) should be ordered separately when ordering the vibratory hammer.

Dimensions	350x550x1300 mm
Weight (approx.)	60 kg (complete set)
Impact Rate	1500-3000/min
Power	1150 W

