

Product Code

UTA-0510 Sand Equivalent Shaker with Safety Cover

Models for 220-240V 50 Hz, 1 ph.	UTC-0510-T
Models for 110-120V 60 Hz, 1 ph.	UTC-0510-
Models for 220-240V 60 Hz, 1 ph.	N UTC-0510-K

Standards

EN 933-8; ASTM D2419; AASHTO T176; UNI 7446

UTA-0510 Sand Equivalent Shaker is used for the uniform shaking of Sand Equivalent Measuring Cylinders, at a specified rate and stroke.

The shaker is supplied complete with a timer. The horizontal movement, cycle and shaking time can easily be adjusted on the shaker to comply with EN or ASTM standards.



Sand Equivalent Shaker Timer

The Sand Equivalent Shaker is supplied complete with •
Safety Cover (conforming with CE directives)
• Timer (on the Shaker)

Horizontal Movemen	200 mm ± 10 mm (EN) 203.2 mm ± 1 mm (ASTM)
t	90 ± 3 / 30 sec. (EN)
Cycle	175 ± 2 / min. (ASTM)
Dimensions	350x800x440 mm
Weight (approx.)	50 kg
Power	200 W