

Product Code

UTA-0806 MICROLANCE Instant Moisture and Temperature Tester

UTA-0806 MICROLANCE Instant Moisture and Temperature Tester is used for the instant on-site determination of moisture and temperature of sands, aggregates, building materials, minerals and mixes from small quantities to hundreds of tons.

The instrument is reliable and easy to use, taking moisture readings up to 1 meter depth by simply inserting the lance into the test material. Instant readings are monitored on the digital display and the built-in computer allows the user to monitor a wide range of materials and water contents.

The UTA-0806 Microlance is supplied with standard calibration values for sands and aggregates but it can also be calibrated for different material or mixture with the Autocal functionality. The unit is supplied complete with a calibration certificate.

	Range	Resolution	Accuracy
Moisture	0 to 25 %	0.1	better than 0.5
Temperature	-20 to 60°C	% 0.1° C	% better than 0.5°C

- Moisture measurement with temperature compensated electric field
- Temperature measurement according to BS 1904 and DIN 751
- Platinum resistance detector
- Works with 4 x 1.5 V AA cells (or equivalent)

Dimensions	100x100x1200
Weight (approx.)	mm 2 kg

