

### Product Code

UTC-4810 Hand Operated Hydraulic Power Pack  
UTC-4920LP LPI Battery Operated Digital Read-Out Unit  
UTC-4810MLP Hand Operated Hydraulic Power Pack  
with LPI Battery Operated Digital Read-Out Unit

The UTC-4810 Hand Operated (Manual) Hydraulic Power Pack has been designed to be used with range of UTEST compression and flexural frames to use on site and/or where electricity is not available.

The pump is equipped with a radial piston pump so that the loading is continuous as long as the user turns the wheel installed on the pump. The loading is uniform as on an automatic machine. The user can easily load up to 400 bars with minimal effort. Maximum working pressure of system is 400 bar.

UTC-4810MLP consists of UTC-4810 and UTC-4920LP. In this application UTC-4920LP is used for reading the applied load by UTC-4810 in any frame.

The specifications of the LPI Battery Operated Digital Read-Out Unit can be seen on UTC-4920LP page.



Dimensions	300x250x500
Weight (approx.)	mm 50 kg