

Product Code

UTCM-0665 Plunger Penetration Apparatus
UTCM-0662E Tamper EN Ø40x200 mm 250 gr

Standards

EN 413-2, 459-2, 1015-4

The UTEST Plunger Penetration Apparatus is used to determine the consistency of fresh mortar, building lime and masonry cement.

The test apparatus consists of a base to place the test cup and a vertical column holding the penetration plunger assembly.

The drop default height is adjusted to 100 mm. The plunger assembly weight is 90 g.

The Plunger Penetration Apparatus is supplied complete with; •

- Test cup, Ø 80 mm x 70 mm
- Tamper



Dimensions	200x200x600
Weight (approx.)	mm 6 kg