

Product Code

UTCM-0666 Air Entrainment Meter for Mortar 1 L
UTCM-0662E Tamper EN Ø 40x200 mm 250 gr

Standards

EN 413-2, 459-2, 1015-7

The UTCM-0666 Air Entrainment Meter for Mortar is used for determining the air content of cement paste, cement mortar and lime mortar.

The air entrainment meter is manufactured from cast aluminum, the upper part and the lower test pot are held together with an air-tight seal which are easily adjusted by using the two spring clamps. The pressure gauge is installed in the head of the meter and the scale works in the 0-20 volumetric % range. The air is compressed with a hand pump installed in the system and the smart configuration of the test and correction buttons enables fast and simple testing.



Dimensions

200x200x320 mm

Weight (approx.)

3,5 kg