

Product Code

UTCM-0680 Bulk Density Apparatus

Standards

EN 459-2

The bulk density of lime is of interest for storage and packaging and for determining volume and capacity of mixing equipment necessary for processing the material.

The UTCM-0680 Bulk Density Apparatus is designed to determine bulk density of lime by allowing a sample to fall from a standard height into a volumetric container.

The apparatus consists of a hopper, 1 liter capacity cylindrical container and a spring-loaded yoke.



Dimensions	Weight (approx.)
250x250x750 mm	2.0 kg