

Product Code

UTCM-0755 Mud Balance

Standards

API Recommended Practice Procedure

The UTCM-0755 Mud Balance, an ideal equipment for site applications, provides an accurate and easy method for determining the mud density. The accuracy of the readings is not affected by the temperature of the drilling mud.

The equipment consists of a base and a graduated arm with an integral spirit level, counter weight, cup, lid, rider, knife-edge. Supplied with a special plastic carrying case which can be used to stabilize the equipment at the working position.



Dimensions	550x110x100
Weight (approx.)	mm 1 kg