

### Product Code

UTCM-0760E Wet Sieving Apparatus, EN

### Standards

EN 451-2; ASTM C430, D1514; AASHTO T192

The UTCM-0760E Wet Sieving Apparatus is used for determining the fineness of fly ash. The apparatus comprises of a special stainless steel sieve, 0.045 mm opening, a spray nozzle Ø 17.5 mm with 17 holes Ø 0.5 mm oriented and spaced to conform to the standards. Supplied complete with a pressure gauge Ø 80 mm and fittings for connection to the water supply.

The UTCM-0560A Wet Sieving Apparatus is used for determining the fineness of hydraulic cement by means of the 45-µm sieve. Water Spray and pressure is controlled.

Dimensions	250x150x150
Weight (approx.)	mm 2 kg

