

Product Code

UTAS-2101 Core Drilling Machine

UTGD-0330 Coring Bit for Asphalt 50 mm dia. x 400 mm length

UTGD-0332 Coring Bit for Asphalt 75 mm dia. x 400 mm length

UTGD-0334 Coring Bit for Asphalt 100 mm dia. x 400 mm length

UTGD-0336 Coring Bit for Asphalt 150 mm dia. x 400 mm length

Standards

EN 12697-27, ASTM D 5361

Machine is designed to cut cores up to 150 mm diameter from concrete, asphalt and similar hard construction materials.

The machine comprises a vertical support column which carries the drill head/motor assembly.

The motor assembly comprises a 6.5 Hp petrol engine.

A ball screw mechanism enables close control of the drilling pressure and rapid return when drilling is completed.

A water spraying assembly is mounted on the machine.

The complete assembly is supplied on a rigid wheel mounted metal base frame with leveling and fixing facility during the operation.

Coring Bits should be ordered separately.



UTGD-0336 UTGD-0334 UTGD-0332 UTGD-0330

Dimensions	500x670x1050
Weight (approx.)	mm 90 kg
Power	6.5 Hp

