

Product Code

- UTGT-1205 Digital Thermometer Immersion Type -50°C to +300°C
- UTGT-1230 Digital Max-Min Thermometer -40 to +50°C
- UTGT-1240 Digital Thermo-Hygrometer, Max-Min Thermometer
- UTGT-1250 Digital Laser Thermometer -50°C to +650°C
- UTGT-1300 Glass Thermometer Max. 60°C
- UTGT-1305 Glass Thermometer Max. 110°C
- UTGT-1310 Glass Thermometer Max. 160°C
- UTGT-1315 Glass Thermometer Max. 250°C
- UTGT-1320 Glass Thermometer Max. 310°C
- UTGT-1325 Glass Thermometer Max. 360°C
- UTGT-1330 Glass Thermometer Max. 400°C
- UTGT-1350 Hand Type Digital Thermometer, -50°C to 1350°C
- UTGT-1352 Temperature Datalogger, 4 Channel Digital Display
- UTGT-1355 Connector, Type: OMTS-K-E for UTGT-1350
- UTGT-1360 Cable, Type: E-0,5 T2KTTEA. Meter for UTGT-1350
- UTGT-1370 200 mm Penetration Probe for Asphalt Temperature Measurement
- UTGT-1371 300 mm Penetration Probe for Asphalt Temperature Measurement
- UTGT-1372 500 mm Penetration Probe for Asphalt Temperature Measurement

UTEST supplies high quality digital and glass thermometers for various applications in the construction industry.

UTGT-1350, UTGT-1352, UTGT-1355 ve UTGT-1360 are used for monitoring of temperature development of mass concrete. The number of measurement points for connectors and the cable length needed for each measurement point should be indicated. The products should be ordered separately.

UTGT-1352 4 Channel Digital Display Temperature Datalogger is an alternative to UTGT-1350 and can record continuously in the time interval selected by the user. The datalogger has -195°C to +1000°C temp. measurement range for K Type sensors, 1s – 24h data record range and 2 million data recording capacity. Battery operated data logger is supplied complete with accessories such as cable for connecting to PC, software, SD card (for collecting the measurement).

Digital thermometer and penetration probes are used together for measuring the delivery and compaction temperatures of bituminous mixtures. Preferred penetration probe should be ordered with UTGT- 1350.



UTGT-1230

UTGT-1352

CAUTION

Please check the laws in your country before ordering mercury thermometers. There may restriction on their sale and shipment for the thermometers contains mercury.



UTGT-1205



UTGT-1250



Glass Thermometers



Product Code	Dimensions	Weight
UTGT-1205	150x150x150 mm	0.2 kg
UTGT-1230	150x150x150 mm	0.2 kg
UTGT-1240	150x150x150 mm	0.2 kg
UTGT-1250	100x100x100 mm	0.2 kg
UTGT-1300	30x30x300 mm	0.1 kg
UTGT-1305	30x30x300 mm	0.1 kg
UTGT-1310	30x30x300 mm	0.1 kg
UTGT-1315	30x30x300 mm	0.1 kg
UTGT-1320	30x30x300 mm	0.1 kg
UTGT-1325	30x30x300 mm	0.1 kg
UTGT-1330	30x30x300 mm	0.1 kg
UTGT-1350	150x80x40	0.3 kg
UTGT-1352	150x80x40	0.3 kg
UTGT-1355	20x10x5	0.01 kg
UTGT-1360	100x100x5	0.01 kg
UTGT-1370	350x50x30	0.5 kg
UTGT-1371	400x50x30	0.5 kg
UTGT-1372	650x50x30	0.6 kg