

Product Code

UTC-3150 Crack Microscope 40x

UTC-4050 Crack Microscope is a high definition device which is used for measuring crack widths both in concrete and other structures like masonry walls. Consists of an adjustable lamp unit and a knob for focusing the image. The 360° turning ability of the eyepiece enables the alignment with the direction of the crack or pitch subject to examination.

The battery operated microscope has 40x magnification and 4 mm measuring range with 0.02 mm subdivisions.

Magnification	40 X
Measuring Range	4 mm
Subdivision	0.02 mm

Dimensions	150x80x45mm
Weight (approx.)	(packed) 550 gr.

