

Product Code

UTC-0580 Compacting Factor Apparatus

Standards

BS 1881-103, 5075

The UTC-0580 Compacting Factor Apparatus is used to determine the compaction factor of concrete with low, medium and high workability.

Comprising two conical hoppers having a hinged trap door attached to the lower end of each hopper, allowing the concrete sample to flow freely into the cylindrical mould.

The hoppers and the mould are mounted onto a rigid steel frame and are easily removable for cleaning.

Dimensions	260x610x1300mm
Weight (approx.)	33 kg

